




ZRA Series Parts Breakdown

Toll Free: 1-800-579-8088 Web: www.zinko.com

REV 091807



No.	Description	No.	Description
1	Screw M10x16L	10	Snap Ring
2	Top Plate	11	Screw Nut
3	*Oil Seal	12	Spring
4	Fasten Nut	13	Screw M6x31L
5	Screw 3/8"x50L	14	Handle
6	*Oil Ring	15	Cylinder
7	Piston Rod	16	Screw
8	*Backup Ring	17	Base
9	*Oil Ring	18	Screw M6x15L
		RP	Repari Kits (All * Above)